

Bearing Assembly Dimensions



LMI Model	A	B	C	Notes
LM - 2	3-5/16"	3-7/8"	2-5/8" x 4 bolt	With Impeller
LM - 3	3-9/16"	3-5/16"	3-3/16" x 4 bolt	With Impeller
LM - 3BG	3-5/16"	3-5/16"	3-3/16" x 4 bolt	New Style B & G
LM - 4	3-1/2"	4-3/8"	3-7/8" x 4 bolt	
LM-5	4-1/4"	4-1/2"	2-5/16" x 8 bolt	
LM - 6	4-1/8"	6-7/8"	2-1/4" x 8 bolt	Bearing Assembly only
LM - 6Plus	4-1/8"	7-1/2"	3-1/4" x 8 bolt	Armstrong Only
LM - 6BG	4-1/8"	8-1/8"	3-1/4" x 8 bolt	B &G Only

